

TED

TRANSFORMING EGG DRONE

Quick Start Guide



We hope you enjoy your purchase of the T.E.D. and use this Quick Guide to get your drone off the ground and taking photos! If you are new to flying drones we suggest reading the full User Manual included in your package.

Getting Started: T.E.D. is an application controlled drone, please install the PANTONMA app in the Play/iTunes Store or by scanning the QR barcode.



iOS



Android



WiFi Connect

Please Note: To operate the drone you must connect to the drone's WIFI through your phone settings.

Step 1 Install the PANTONMA app onto your Android or iOS phone.

Step 2 Press down the power button on the underside of the drone for 3 seconds.

Step 3 Through your phone settings, connect to the WIFI signal named KD****.

Step 4 Open the PANTONMA app and click MY DRONE. The drone and the app will connect.*

*If the drone does not connect try again or check your batteries.

 **Step 5** Tap the Take Off button to start the drone. The propellers will start to spin and take off.

Fly Your Drone



Ascending: Tap the left throttle stick upwards to make the T.E.D. go up.



Descending: Tap the left throttle stick downwards to lower the T.E.D.



Forward Backward: Tap the right throttle stick up and down to go forward and backward.



Rotating: Tap the left throttle stick left or right to turn in a specific direction.



Strafing: Tap and hold the right throttle stick left or right to move in that direction.



Landing: Gently ease the left throttle stick downward until landing on the ground.



Auto Takeoff/Landing: Tap to take off and come to about 5 ft. altitude. During flight, tap to auto land your drone.



Gravity Sensor: Tap the Gravity Sensor Control Button and keep your thumb on the right throttle stick. Move your phone in any direction and the drone will respond.



Cameras: Tap the camera or video icon to take a photo or video.

If you have any issues, contact us before returning your product to the dealer/store. We will be glad to help you in any way possible. Tel 305-933-4480



Check out our YouTube channel for instructional videos and more!  /OdysseyToys

Care@OdysseyToys.com • www.OdysseyToys.com

   ODYSSEYTOYS