

# POCKET DRONE 2

## Quick Start Guide



We hope you enjoy your purchase of the Pocket Drone 2 and use this Quick Guide to get your drone off the ground and taking photos! If you are new to flying drones we suggest reading the full User Manual included in your package.

**Getting Started:** Pocket Drone 2 is an application controlled drone, please install the app ODY Pocket Drone in the Play/iTunes Store or by scanning the QR barcode.



iOS



Android



### WiFi Connect

**Please Note:** To operate the drone you must connect to the drone's WIFI through your phone settings.

**Step 1** Install the ODY Pocket Drone app onto your Android or iOS phone.

**Step 2** Press the power button on the drone to turn on the drone, the lights will flash.

**Step 3** Through your phone settings, connect to the WIFI signal named Pocket Drone 2.

**Step 4** Open the Odyssey app and click connect. The drone and the app will connect\* and you can take flight by pressing the OFF button.

\*If the drone does not connect try again or check your batteries.

**Step 5** Tap the Ignition button.

**Step 6** Tap the Auto Take Off to start the drone. The propellers will start to spin and take off.

If you have any issues, contact us before returning your product to the dealer/store. We will be glad to help you in any way possible. Tel. 1.866.306.5177

### Fly Your Drone



**Ascending:** Tap the left throttle stick upwards to make the Pocket Drone go up.



**Descending:** Tap the left throttle stick downwards to lower the Pocket Drone.



**Forward Backward:** Tap the right throttle stick up and down to go forward and backward.




**Rotating:** Tap the left throttle stick left or right to turn in a specific direction.



**Strafing:** Tap and hold the right throttle stick left or right to rotate in that direction.



**Landing:** Gently ease the left throttle stick downward until landing on the ground.



**WayPoints:** Tap the waypoint icon. Draw your flight patterns on the screen.



**Gravity Sensor:** Tap the Gravity Sensor Control Button and keep your thumb on the right throttle stick. Move your phone in any direction and the drone will respond.



**Cameras:** Tap the camera or video icon to take a photo or video.



Check out our YouTube channel for instructional videos and more! [YouTube /OdysseyToys](#)

Care@OdysseyToys.com • www.OdysseyToys.com

[f](#) [t](#) [v](#) [i](#) [o](#) [d](#) **ODYSSEYTOYS**